

Elink Defense

APP User manual



U Version: 1.0

Contents

1. Search “Elink defense” in Google Play or Apple Store, or scan the QR code to download and install the app.	3
2. Follow the startup wizard, scan the QR Code to download app, then register and login to add this NVR quickly	4
3. Open the app and check the agreement, tap Sign Up to register an account by email address.	5
4. Login app, tap top-right + to scan the above P2P QR code to add the device.	6
5. Live view and playback on mobile phone via app	7
6. To receive Push Alarm Message, firstly tap the Message then tap the aquamarine notice bar goto Alarm Notification Settings when pop-up. Follow the steps to enable alarm notification.	8
7. Reset NVR password by app	11


Remote Access via Smart Phone App

This NVR supports Android and iPhone app remote access. Follow the steps below to make it work.


1. Search “**Elink defense**” in Google Play or Apple Store, or scan the QR code to download and install the app.





2. Follow the startup wizard, scan the QR Code to download app, then register and login to add this NVR quickly .





If no startup wizard pop-up, Go to Main Menu -> **Network** -> **Basic** -> **P2P**, make sure the **Enable P2P** is on.






3. Open the app and check the agreement, tap **Sign Up** to register an account by email address.



4. Login app, tap top-right + to scan the above P2P QR code to add the device.



5. Live view and playback on mobile phone via app





PTZ: to control high speed dome camera or motorized lens zoom;

Two-way audio: speak to current camera;

Alarm: trigger relay or red-blue lights;

Image adjust: adjust flip, mirror, rotate, brightness, sharpness, DNR ...;

6. To receive **Push Alarm Message**, firstly tap the **Message** then tap the aquamarine notice bar goto **Alarm Notification Settings** when pop-up. Follow the steps to enable alarm notification.





Elink Defense

Show notifications

Notification spotlight
Use custom notification format to highlight important info

Notification permissions

Notification badges
Allow a numbered red dot to be shown on Home screen icons to indicate notifications or new content

Floating notifications
Allow floating notifications


Lock screen notifications
Allow notifications on the Lock screen

Sound

Vibration

Permanent notifications
Allow notifications that can only be deleted manually


Notification categories





When event happen the message will push to lock-screen and app Message list.

7. Reset NVR password by app



Goto **Me** -> **Tools**, click **Forget password**, scan the QR Code in GUI menu, the password reset Security Code will send to the email address you set before. After filling the correct code, and press **OK** the NVR password will be reset to **123456**. Please change your own password for daily use.

***Note:** please make sure the email address is absolutely correct; otherwise, you won't receive the verification code, you have to send the QR code to the supplier to get the Security Code .